



ReKEY_{nano}

ReKEY Nano Pro:Idiom® Refresh Device

OPERATION MANUAL

Although every effort has been taken to ensure the accuracy of this document it may be necessary, without notice, to make amendments or correct omissions. Specifications subject to change without notice.

MDU Solutions®, UCrypt®, DigiVu® and VersActive®Pro are registered trademarks of ATX in the United States and/or other countries. Products or features contained herein may be covered by one or more U.S. or foreign patents. Motorola®, Cisco®, and other non-ATX product and company names in this manual are the property of their respective companies.

TABLE OF CONTENTS

1.	<u>RE-KEYING CORRUPTED Pro:Idiom® TVS</u>	1-1
2.	<u>Pro:Idiom® KEY RENEWAL PROCESS WITH ReKEY NANO</u>	2-1
3.	<u>SERVICE & SUPPORT</u>	3-1
3.1	<u>Contact ATX Networks</u>	3-1
3.2	<u>Warranty</u>	3-1

This page intentionally left blank.

RE-KEYING CORRUPTED Pro:Idiom® TVs

1. Re-keying Corrupted Pro:Idiom® TVs

- Capable of streaming key refresh file via configurable agile QAM directly to a TV with a corrupted/lost Pro:Idiom key
- Compact & light form factor for ease of portability by technicians
- LCD display & pushbutton control for quick & easy configuration
- RF output port for direct connection to the TV with a coax jumper

This page intentionally left blank.

Pro:Idiom® KEY RENEWAL PROCESS WITH ReKEY NANO

2. Pro:Idiom® Key Renewal Process with ReKEY Nano

- Determine QAM frequency & MPEG program number mapping of a non-functional Pro:Idiom encrypted program on the TV
- Plug-in & power on the ReKEY device, wait for boot up
- Enter the selected program's QAM frequency & program number into the ReKEY device via LCD screen menu
- Tune TV to selected non-functional channel & connect coax-jumper from the ReKEY device RF output port to the TV's RF input port
- Select "Stream" from the ReKEY device menu
- Wait for color bars & Pro:Idiom logo to appear on TV
- Disconnect ReKEY device & reconnect main RF feed & verify previously non-functional channel is working

This page intentionally left blank.

SERVICE & SUPPORT

3. Service & Support

3.1 Contact ATX Networks

Please contact ATX Technical Support for assistance with any ATX products. Please contact ATX to obtain a valid RMA number for any ATX products that require service and are in or out-of-warranty before returning a failed module to ATX.

TECHNICAL SUPPORT

Tel: 289.204.7800 – press 1
Toll-Free: 866.YOUR.ATX (866.968.7289) USA & Canada only
Email: support@atx.com

SALES ASSISTANCE

Tel: 289.204.7800 – press 2
Toll-Free: 866.YOUR.ATX (866.968.7289) USA & Canada only
Email: insidesales@atx.com

FOR HELP WITH AN EXISTING ORDER

Tel: 289.204.7800 – press 3
Toll-Free: 866.YOUR.ATX (866.968.7289) USA & Canada only
Email: orders@atx.com
Web: www.atx.com

3.2 Warranty Information

All of ATX Networks' products have a 1-year warranty that covers manufacturer's defects or failures.



© 2019 by ATX Networks Corp. and its affiliates (collectively "ATX Networks Corp."). All rights reserved. This material may not be published, broadcast, rewritten, or redistributed. Information in this document is subject to change without notice.

Rev. 11/19 (ANW1225)



ATX Networks

Tel: 289.204.7800 | Toll-Free: 866.YOUR.ATX (866.968.7289) | support@atx.com

www.atx.com